

Ident - Nummern - Konstante
3740

Gebrauchsanweisung
51 5102
(D,GB,F,I,NL,DK,N,
S,SF,P)

- 1) 02 8829
- 2) 02 0665
- 3) 02 7247
- 4) 02 7248
- 5) 02 7249
- 6) 02 7256

Zubehör:



MCZ2ZP2
Zitruspresse





MCZ2FW1
Fleischwolf

MCZ2RS1
Reibscheibe grob



MCZ2PS1
Pommes-Frites-
Scheibe

MCZ2GM1
Getreidemühle mit
Stahlmahlwerk





08 6126



0029	00055088		Csatlakozókábel
0030	00084379		Szán
0031	00084380		Meghajtás
0032	00085228		Tartó
0033	00087057		Meghajtótengely
0034	00117022		Burkolat
0035	00117038		Burkolat alsó rész
0036	00515102		Használati útmutató